



**AREVA**

forward-looking energy



# AREVA Computer Codes for Radiological Consequence Analysis

Silke Torchiani, Oliver Buss, Stéphane Haussler,  
Oliver Ludwik, Axel Hoefer  
AREVA GmbH, Offenbach, Germany

IAEA, Vienna, 20<sup>th</sup>-24<sup>th</sup> April, 2015

# Agenda

1

**Our Involvement**

2

**CompAct – Compartment Code for Source Term Evaluation**

3

**DOT – Dose Evaluation Tool**

4

**CRCS – Central Radiological Computer System**

# Agenda

1

## Our Involvement

2

CompAct – Compartment Code for Source Term Evaluation

3

DOT – Dose Evaluation Tool

4

CRCS – Central Radiological Computer System

# Our involvement

## New builds and installed base

### Our activities encompass

- ▶ **EPR™ Power Plants**
  - ◆ **Olkiluoto 3**
  - ◆ Taishan units 1 & 2
- ▶ Installed base
  - ◆ Periodic safety review
- ▶ Emergency response
  - ◆ Tools & methods



# Our involvement

## New builds and installed base

### Our activities encompass

#### ▶ **EPR™ Power Plants**

- ◆ Olkiluoto 3

- ◆ **Taishan units 1 & 2**

#### ▶ Installed base

- ◆ Periodic safety review

#### ▶ Emergency response

- ◆ Tools & methods



# Our involvement

## New builds and installed base

### Our activities encompass

- ▶ **EPR™ Power Plants**
  - ◆ Olkiluoto 3
  - ◆ Taishan units 1 & 2
- ▶ **Installed base**
  - ◆ **Periodic safety review**
- ▶ **Emergency response**
  - ◆ Tools & methods





# Our involvement

## New builds and installed base

### Our activities encompass

- ▶ **EPR™ Power Plants**
  - ◆ Olkiluoto 3
  - ◆ Taishan units 1 & 2
- ▶ **Installed base**
  - ◆ Periodic safety review
- ▶ **Emergency response**
  - ◆ Tools & methods





# Our involvement

## New builds and installed base



### Our activities encompass

- ▶ **EPR™ Power Plants**
  - ◆ Olkiluoto 3
  - ◆ Taishan units 1 & 2
- ▶ **Installed base**
  - ◆ Periodic safety review
- ▶ **Emergency response**
  - ◆ Tools & methods

**Preparation of the safety  
analyses for licensing**

**Safety assessments for the  
design of our new products**

**Emergency response**

# Codes and methods

## Radiological consequences assessments

Different purposes, different objectives,  
different analyses: customized tools

### ► Purpose

- ◆ Design
- ◆ Licensing
- ◆ Emergency preparedness
- ◆ Emergency response

### ► Scope

- ◆ Activity releases into the environment
- ◆ Activity in rooms and systems
- ◆ Atmospheric dispersion and dose assessment



# Codes and methods

## Radiological consequences assessments



Different purposes, different objectives,  
different analyses: customized tools

### ► Purpose

- ◆ Design
- ◆ Licensing
- ◆ Emergency preparedness
- ◆ Emergency response

### ► Scope

- ◆ Activity releases into the environment
- ◆ Activity in rooms and systems
- ◆ Atmospheric dispersion and dose assessment



# Codes and methods

## Radiological consequences assessments


Different purposes, different objectives,  
different analyses: customized tools

### ► Purpose

- ◆ Design
- ◆ Licensing
- ◆ **Emergency preparedness**
- ◆ **Emergency response**

### ► Scope

- ◆ **Activity releases into the environment**
- ◆ **Activity in rooms and systems**
- ◆ **Atmospheric dispersion and dose assessment**



# Codes and methods

## Necessary features



Tools must be versatile in order to address existing and foreseeable situations for design, licensing, emergency preparedness and emergency response

# Agenda

1

Our Involvement

2

**CompAct – Compartment Code for Source Term Evaluation**


3

DOT – Dose Evaluation Tool

4

CRCS – Central Radiological  
Computer System





## Integrated compartment model

### ► Airborne release

- ◆ Immediate or continuous
- ◆ Evaporation of liquids
- ◆ Equilibrium processes

### ► Multi-compartment transport



- ◆ Active ventilation
- ◆ Leakage pathways
- ◆ Bypass


### ► Radioactive decay and ingrowth

### ► Removal processes

- ◆ Filters
- ◆ Dry deposition
- ◆ Spray

### ► Individual chemical forms







## A few selected features

- ▶ **State-of-the art solver for large, stiff ODE systems**
- ▶ **Internal verification of numerical precision**
- ▶ **Intuitive graphical user interface**
- ▶ **Easy adaptation to various requirements**
- ▶ **Arbitrarily complex models**
- ▶ Convenient output
- ▶ Model checks itself for validity and completeness

ODE = ordinary differential equation





## A few selected features

- ▶ State-of-the art solver for large, stiff ODE systems
- ▶ Internal verification of numerical precision
- ▶ Intuitive graphical user interface
- ▶ Easy adaptation to various requirements
- ▶ Arbitrarily complex models
- ▶ **Convenient output**
- ▶ Model checks itself for validity and completeness

Model    Model Check    Kernel: Input File    Kernel: Log Messages    Kernel: Results


Physical Parameter    Activities    Representation    Table    Compartment    Core

File name: D:\work\Compact\trunk\examples\Neuer Ordner\compact\_numeric\_activities\_Core.out  
Date: Thu Oct 23 16:17:12 2014

**Numerical results for activities in compartment Core in units of Bq and h**


☐ Show only non-zero-columns


	time	Br84	Kr85	Kr85m	Kr87	Kr88	Rb86	Rb88	Sr89
1	-1.17800000E+02	9.65550000E+17	3.61100000E+16	1.10990000E+18	2.27650000E+18	3.20280000E+18	6.18580000E+15	3.26560000E+18	4.14480000E+18
2	-1.00000000E-02	0.00000000E+00	3.60898092E+16	1.35056280E+10	2.98298674E-10	1.04762235E+06	5.15489180E+15	1.16982207E+06	3.87478435E+06
3	0.00000000E+00	0.00000000E+00	3.60846461E+16	1.34828200E+10	2.96634782E-10	1.04491914E+06	5.15473830E+15	1.16695217E+06	3.87476164E+06
4	1.00000000E-01	0.00000000E+00	3.60846195E+16	1.32758188E+10	2.80899269E-10	1.01972493E+06	5.15394054E+15	1.13878821E+06	3.87454004E+06
5	1.00000000E+00	0.00000000E+00	3.60843801E+16	1.15501212E+10	1.71991681E-10	8.18627269E+05	5.14676620E+15	9.14130268E+05	3.87254628E+05
6	2.00000000E+00	0.00000000E+00	3.60841141E+16	9.89446567E+09	9.97224205E-11	6.41342071E+05	5.13880642E+15	7.16152692E+05	3.87033219E+05
7	3.00000000E+00	0.00000000E+00	3.60838481E+16	8.47614057E+09	5.78200124E-11	5.02450465E+05	5.13085895E+15	5.61058845E+05	3.86811937E+05
8	4.00000000E+00	0.00000000E+00	3.60835821E+16	7.26112570E+09	3.35245958E-11	3.93637781E+05	5.12292377E+15	4.39553603E+05	3.86590781E+05
9	5.00000000E+00	0.00000000E+00	3.60833161E+16	6.22027749E+09	1.94378810E-11	3.08390008E+05	5.11500087E+15	3.44362107E+05	3.86369751E+05
10	6.00000000E+00	0.00000000E+00	3.60830501E+16	5.32862998E+09	1.12702692E-11	2.41603833E+05	5.10709022E+15	2.69785670E+05	3.86148848E+05
11	7.00000000E+00	0.00000000E+00	3.60827841E+16	4.56479595E+09	6.53460978E-12	1.89281140E+05	5.09919180E+15	2.11359805E+05	3.85928071E+05
12	8.00000000E+00	0.00000000E+00	3.60825182E+16	3.91045392E+09	3.78882920E-12	1.48289659E+05	5.09130560E+15	1.65586880E+05	3.85707421E+05
13	9.40000000E+00	0.00000000E+00	3.60821458E+16	3.14887412E+09	1.76646300E-12	1.05369713E+05	5.08028540E+15	1.17660545E+05	3.85398722E+05
14	9.41000000E+00	0.00000000E+00	3.60821431E+16	3.14400594E+09	1.75686099E-12	1.05112855E+05	5.08020677E+15	1.17373725E+05	3.85396518E+05
15	1.71000000E+01	0.00000000E+00	3.60800978E+16	9.56665240E+08	2.65706323E-14	1.60895138E+04	5.07009932E+15	1.79667723E+04	3.83705299E+04



## A few selected features



- ▶ State-of-the art solver for large, stiff ODE systems
- ▶ Internal verification of numerical precision
- ▶ Intuitive graphical user interface
- ▶ Easy adaptation to various requirements
- ▶ Arbitrarily complex models
- ▶ **Convenient output**
- ▶ Model checks itself for validity and completeness





## A few selected features

- ▶ State-of-the art solver for large, stiff ODE systems
- ▶ Internal verification of numerical precision
- ▶ Intuitive graphical user interface
- ▶ Easy adaptation to various requirements
- ▶ Arbitrarily complex models
- ▶ Convenient output
- ▶ **Model checks itself for validity and completeness**



# Agenda

1

Our Involvement

2

CompAct – Compartment Code for Source Term Evaluation

3

**DOT – Dose Evaluation Tool**


4

CRCS – Central Radiological Computer System



## Radiological consequences assessments for design & licensing

- ▶ Gaussian atmospheric dispersion
- ▶ Dose calculations
  - ◆ Cloud-shine
  - ◆ Inhalation
  - ◆ Beta submersion
  - ◆ Ground-shine
  - ◆ Ingestion
- ▶ Contamination of foodstuff




Source: MACCS2 Computer Code Application Guidance for Documented Safety Analysis, 2004






## A few selected features

- ▶ **Independent kernel and graphical user interface (GUI)**
  - ◆ DOT kernel is a library (.dll)
  - ◆ The kernel can be re-used
- ▶ **Interface with CompAcT**
- ▶ **Simplify**
  - ◆ Calculations
  - ◆ Documentation
- ▶ **User-friendly GUI**



## A few selected features

- ▶ Independent kernel and graphical user interface (GUI)
  - ◆ DOT kernel is a library (.dll)
  - ◆ The kernel can be re-used
- ▶ Interface with CompAcT
- ▶ **Simplify**
  - ◆ Calculations
  - ◆ Documentation
- ▶ **User-friendly GUI**



# Agenda

1

Our Involvement

2

CompAct – Compartment Code for Source Term Evaluation

3

DOT – Dose Evaluation Tool

4


**CRCS – Central Radiological Computer System**

## Motivations

**A real life accident will not follow a fixed scenario and will deviate from the assumptions of the safety analysis report**

- ▶ What is the radioactive source term of a design-exceeding event?
- ▶ What is the impact of such an event on the surrounding areas?
- ▶ How can the impact on the population be assessed and minimized?





## Objective, Benefits, and Application of CRCS

- ▶ **CRCS** is a modular tool for supporting the radiological staff of a Nuclear Power Plant with Radiological Surveillance and Emergency Preparedness (Crisis Center)
- ▶ **CRCS** is part of the EPR™ Design for Taishan 1+2 and Olkiluoto 3
- ▶ **CRCS** is easily adaptable to site-specific needs





## Approach

### ► Starting Point

- ◆ Power-plant-specific **activity source term** (PC, core, etc.), **system parameters** (ventilation rates, leakage rates, etc.) and thermo-hydraulic data (core release fractions, deposition fractions, etc.)
- ◆ Modelling the **accident sequence** in terms of a system of differential equations
- ◆ Definition of modifiable key parameters for adaptation of the release calculation to real case

### ► **Adaptation** of model parameters to reproduce **measurements**

- ◆ Real sequence is reflected by the model
- ◆ Activity measurements and system parameters within the plant
- ◆ Meteorological and dose rate measurements (environment)



## Accident selection among pre-defined scenarios

Activity releases into the  
environment

Meteorological conditions

Radiological consequences  
assessment

- Large Break Loss of Coolant Accident
- Small Break Loss of Coolant Accident
- Rod Ejection Accident
- Steam Generator Tube Rupture
- Loss of Condenser Vacuum
- Long Term Loss of Offsite Power
- Locked Rotor Accident
- Loss of Coolant outside Containment
- Leakage in the Gaseous Waste Processing System
- Fuel Handling Accident
- Effect of Earthquake on Nuclear Auxiliary Building / Waste Building
- Core Melt Sequence: initiated by a Large-Break Loss of Coolant Accident
- Core Melt Sequence: initiated by a Loss of Offsite Power




Accident selection among  
pre-defined scenarios

**Activity releases into the  
environment**

Meteorological conditions

Radiological consequences  
assessment



Accident selection among  
pre-defined scenarios

Activity releases into the  
environment

**Meteorological conditions**

Radiological consequences  
assessment

#### Distribution of wind directions and speeds


WindRose  
relative frequency of wind directions per sector

2011.01.01 00:00 - 2011.01.05 00:00  
60-minutes average values

Wind measurement height: reasonable -> 100m

<b>Availability:</b>		
Dates:	96	
Available:	96	(100.0%)
Substitution values:	0	(0.0%)
Not available:	0	(0.0%)
Wind calm:	4	(4.2%)

CRCS Plav 7482 on Dev013. Created 2014/07/14/15/29




Accident selection among  
pre-defined scenarios


Activity releases into the  
environment

Meteorological conditions

Radiological consequences  
assessment









## Special Tool: e.g. for Venting

- ▶ Pre-calculated accident sequence and correction due to venting process and real conditions (measurements: pressure, dose rate)
- ▶ Release fractions and depositions taken from thermo-hydraulic calculations
- ▶ Transport calculation of venting and leakage into the annulus



## Special Tool: e.g. for Venting

- Display of pressure and dose including measurements in the containment
- Release rates and integral release



### Scenario

Time of shut down: 2014/06/04/00/00

Time of initiating event: 2014/06/04/00/00

Accident scenario:

Open RVP + LUHS

### Venting

	Start	End	Enable
Venting phase 1:	2014/06/05/16/00	2014/06/05/21/00	<input checked="" type="checkbox"/>
Venting phase 2:	2014/06/06/06/00	2014/06/06/21/00	<input checked="" type="checkbox"/>
Venting phase 3:	-----	-----	<input type="checkbox"/>

Scale to m

### Filter factors for venting

	Default	
Aerosol (0.0-1.0)	0.99	0.99
Elemental iodine (0.0-1.0)	0.99	0.99
Organic iodine (0.0-1.0)	0.99	0.99

### Leakage to Annulus

☒ Calculate leakage to annulus

Default

Leakage rate at design pressure (5.3 bar abs.) in 1/s: 5.780e-08 5.780e-08

Annulus volume in m³: 6000 6000


Annulus vent rate: Containm. leak rate

Vent rate in m³/h (200-2000 m³/h):

### Filter factors for annulus ventilation system

	Default	
Aerosol (0.0-1.0)	0.99	0.99
Elemental iodine (0.0-1.0)	0.99	0.99
Organic iodine (0.0-1.0)	0.99	0.99

### Physical Properties [bar] Dose Rate [Sv] Release Rate [Bq/s] Integral Release [Bq]



Plot options:

☒ Aerosol

☒ Noble Gas

Time period: 1 h DGL time step [minutes]: 1

Replot

# Summary

## Codes and methods


Different purposes, different objectives,  
different analyses: customized tools

► Purpose

- ◆ Design
- ◆ Licensing
- ◆ Emergency preparedness
- ◆ Emergency response

► Scope

- ◆ Activity releases into the environment
- ◆ Activity in rooms and systems
- ◆ Atmospheric dispersion and dose assessment



“ *This document contains elements protected by intellectual property rights as well as confidential information.*

*Any reproduction, alteration, transmission to any third party or publication in whole or in part of this document and/or its content is prohibited unless AREVA has provided its prior and written consent. This prohibition concerns notably any editorial elements, verbal and figurative marks and images included herein.*

*This document and any information it contains shall not be used for any other purpose than the one for which they were provided. In particular, no patent application and/or registered design may be applied for on the basis of the information contained herein.*

*Legal action may be taken against any infringer and/or any person breaching the aforementioned rules.*

*No warranty what so ever, express or implied, is given as to the accuracy, completeness or fitness for a particular use of the information contained in this document. In no event AREVA shall be liable for any damages what so ever including any special, indirect or consequential damages arising from or in connection with access to, use or misuse of the information contained in this document.*”