



TEXAS A&M
UNIVERSITY

Quantitative Microbial Risk Assessment to Accelerate Adoption of Electron Beam Technologies for Fresh Produce Safety and Quality in the United States

Shima Shayanfar

National Center for Electron Beam Research

an IAEA Collaborative Center for eBeam technology

Texas A&M University

Harnessing eBeam Technologies for Cleaning Healing, Feeding, and Shaping this World, and Beyond...

Outline

Fresh produce today!

eBeam technology
Changing paradigms

Food Safety vs Food Quality

**Quantitative Microbial
Risk Assessment (QMRA)**

Case studies

Take-Home Messages

What's going on???



- 23 million US children are either obese or overweight because of poor dietary habits (*IFT, 2005*)

21st Century Reality



Food Safety & Food
Quality




Environmental
Quality

ONE-HEALTH



Public Health



Animal Health

Globalization is Changing Everything

- The structure of the global food industry is continually changing
- Global food supply is evolving as food suppliers, manufacturers, & retailers adjust to meet the expectations of consumers
- **Global Food Safety Initiative (GFSI)**
 - *Affecting food sourcing*
 - *Affecting food production and organization*
 - *Affecting food ingredients*
 - *Affecting food processing*



Reality today

- Food Safety is NOT a competitive advantage!

- **Food quality is # 1**

- Global harmonization


Diminishing regional influence



Corporate influence is supreme

Either Play or get out!



Key Question


$$E = mc^2$$



Food Irradiation Technology

- Most extensively studied technology with over 100 years of data
- Approved in over 60 countries
- **Used routinely in the United States, Europe and Asia**
 - In the US, irradiated fresh produce increased > 6000% since 2007!!
 - In the US, volume increased over 13% from 2012-2013!!
- **NOT ONE irradiated food item has been removed from shelves due to consumer complaints**
- **Consumer Acceptance is NOT an issue**



Widespread Erroneous Information

- Consumers will not buy irradiated foods
- Food irradiation has failed in the United States
- European Union consumers will not accept irradiated foods
- The technology is not cost-effective
- eBeam irradiation is not effective for surface decontamination
- eBeam does not penetrate packaged products

Imported Fruits and Vegetables in US by Irradiation



Guava



Mango



Papaya



Star Fruit



Cuban Sweet Potato



Okinawa Sweet Potato



Lychee



Rambutan



National Center for Electron Beam Research

an IAEA Collaborative Centre for eBeam technology

eBeam processing of imported produce at Texas A&M



Harnessing eBeam Technologies for Cleaning Healing, Feeding, and Shaping this World, and Beyond...

eBeam Doses and Applications


Application	eBeam dose
Sprouting Inhibition	0.1 kGy – 0.2 kGy
Insect Disinfestation	0.1 kGy – 0.4 kGy
Protozoan Control	0.3 kGy -0.5 kGy
Delay of Ripening	0.5 kGy – 1.0 kGy
Controlling Fungi	1.5 kGy – 3.0 kGy
Bacterial Pathogen Control in foods	1.5 kGy – 3 kGy
Viral pathogen Control in foods	3 kGy – 10 kGy
Terminal Sterilization	15 kGy – 30 kGy
Polymerization	25 kGy – 50 kGy
Polymer Grafting	25 kGy – 50 kGy
Polymer Crosslinking	50 kGy – 150 kGy
Material degradation	500 kGy – 1500 kGy
Coloring gemstones	>>> 1500 kGy

U.S. Food Vending Business



~ \$ 20- billion vending industry


CHART 1: INDUSTRY REVENUE IN BILLIONS, 10-YEAR REVIEW



100 million people use food vending machines daily

market vendingwatch.com
IFT, 2005


Synergistic effect of eBeam with MAP



Normal Atmosphere



Normal Packaging




MAP

MAP + eBeam



Lower bioburden was seen in eBeam treated grapes under modified atmosphere




- The bioburden of grapes in modified atmospheres was reduced using eBeam technology

Sensory Evaluation in Grapes



Grape Flavor



EB = 82%

EB+M= 88


Air = 88

MAP = 82


Grape flavor and texture was highly liked by consumers

Grape Texture

EB = 82%
EB+M = 88
Air = 88
MAP = 77




eBeam reduced bioburden in modified atmosphere packaged watermelon



- eBeam lowered bioburden levels in MAP watermelon on all days of storage

Watermelon redness not affected by eBeam or modified atmospheres




- E-beam did not adversely affect watermelon redness (lycopene)
- Modified atmospheres did not affect redness of watermelon

Sensory Evaluation in Watermelon



Watermelon Color




EB	75%
EB+MAP	44%
Air	63%
MAP	58%

75 % of consumers rated e-beam (in air) as 7-moderately to 9-extremely like

Watermelon Appearance

EB	69%
EB+MAP	63
Air	75
MAP	55


Watermelon appearance was highly liked.



How is your food ?



Quantitative Microbial Risk Assessment (QMRA)



Risk Analysis Framework



Risk Assessment

- Involves 4 basic steps
- **Hazard identification**
- **Exposure assessment**
- **Dose-response assessment**
- **Risk characterization**

QMRA Overview

- **Hazard Identification**
 - Which pathogen(s)?
- **Exposure Assessment**
 - How many pathogens are individuals or populations exposed to?
 - What are the contamination scenarios?
 - What are the adverse health effects?
- **Dose-response Assessment**
 - What is the relation between exposure and health effects?
 - What is the infective dose of the pathogen(s)?
- **Risk Characterization**
 - How does temporal, spatial and inherent variability affect risk?
 - Do properties that are unique to the pathogen or infectious diseases (such as person-person transmission or immunity) need to be accounted for?
 - What methods are appropriate or needed to characterize risk?

Can eBeam Reduce Infection Risks from Rotavirus and Poliovirus on Lettuce?

Assuming Serving size of lettuce (14 g) contaminated ~ 10 viruses

What would be the reduction in Infection Risks if eBeam pasteurization at 3 kGy is performed?

Quantitative Microbial Risk Assessment in Lettuce



- standard US single serving sizes of lettuce (14g)
- HAV and NoV virus loads were assumed to be 1, **10**, **100** and **1000 PFU/g** of either lettuce or spinach
- Infection risks calculated based on beta-Poisson model for rotavirus and Exponential model for poliovirus
- Single exposure

The beta-Poisson model, $P_i = 1 - (1 + N/\beta)^{-\alpha}$,


*P_i = the probability of infection, N = the number of viruses ingested.
The parameters α (0.2531) and β (0.42) represent parameters of the dose-response curve.*



eBeam Reduces Infection Risks from Rotavirus and Poliovirus on Lettuce

Assuming Serving size of lettuce (14 g) contaminated ~ 10 viruses

What would be the reduction in Infection Risks if eBeam pasteurization at 3 kGy is performed?



Espinosa et al., AEM, Feb 2012


Quantifying the Reduction in Potential Health Risks by Determining the Sensitivity of Poliovirus Type 1 Chat Strain and Rotavirus SA-11 to Electron Beam Irradiation of Iceberg Lettuce and Spinach

Ana Cecilia Espinosa,^a Palmy Jesudhasan,^b René Arredondo,^a Martha Cepeda,^b Marisa Mazari-Hiriart,^a Kristi D. Mena,^c and Suresh D. Pillai^b

Universidad Nacional Autónoma de México, Laboratorio de Ecología Química, Instituto de Ecología, Mexico City, Mexico^a; National Center for Electron Beam Research, Food Safety & Environmental Microbiology Program, Texas A&M University, College Station, Texas, USA^b; and University of Texas Health Science Center at Houston, School of Public Health, El Paso Regional Campus, El Paso, Texas, USA^c

QMRA of non-O157 Toxigenic *E.coli* Reduction by *eBeam* on Strawberries

Serving size of strawberries (1 cup, (152 g)) contaminated ~ 10 CFU of STEC
treated with eBeam at < 1 kGy




Take-Home Messages!

- Safety is essential for fresh produce However quality is a value addition
- Food irradiation SHOULD NEVER be used as a clean-up technology
- Food irradiation SHOULD ONLY be used as an integral step of comprehensive GAP, GMP, HACCP plans
- Microbial studies limited to log reductions cannot be an ultimate indication of safety of food
- Risk assessment provides risk management and risk communication tools for decision makers



New Book!!!



- Combining eBeam technology with
 - *Pulsed electric field (PEF)*
 - *High Pressure Processing (HPP)*
 - *Infrared*
 - *Ultrasound*
 - *Cold plasma*
 - *Active packaging*
 - *Modified atmosphere packaging (MAP)*

.....coming out January 2015



Harnessing eBeam Technologies for Cleaning Healing, Feeding, and Shaping this World, and Beyond...



Shima Shayanfar

shayanfar@tamu.edu

[*http://ebeam.tamu.edu*](http://ebeam.tamu.edu)